



V7 Pass-Thru Flash a Controller

EFILive Support - 2020-07-13 - V7 Software

1. Connect **FlashScan V1** device to your PC and vehicle.
2. Turn the vehicle ignition to the **On** position (not the **Accessory** position. Vehicle must not be cranked/running when flashing).
3. Open the **EFILive Tune Tool** application.
4. Click on the **File** menu and select the **Open tuning file...** menu option.
5. Select the calibration file for the controller you wish to license.
6. Click on the **Flash** menu and select the **Program PCM calibrations...** menu option.
7. Click the **Start** button.
8. If the controller is not licensed a information dialogue will be shown.
9. Click the **License ECM** button that will have appeared.
10. Select **Yes** and **OK** to the next two prompts to confirm you wish to license the controller.