



## V3 Read a Controller


EFILive Support - 2021-07-14 - Comments (0) - AutoCal V3 Vehicle Communications

Follow these steps to read the selected controller.

NOTE: Not all Supported controllers can be read. Some vehicle manufacturers have disabled the ability to read the contents of a controller from the factory. In these cases, EFILive customers will need to obtain base files from an alternative source. Some EFILive Custom Operating Systems are written to non-readable memory. These files cannot be read from controller. Refer to the [Problems Reading a Controller](#) article for further information.


### Standard Menu

1. Configure [FlashScan/AutoCal V3 for BBX](#) features if not already setup.
2. Connect your **FlashScan/AutoCal V3** device to your vehicle.
3. Turn the vehicle ignition to the **On** or **Accessory** position (vehicle must not be cranked/running when reading).
4. Navigate to the **Tune Tool -> F1 Tuning -> F1 Read Tune** menu option.
5. Select correct controller type from BBX configured controllers.
6. Click the ✓ button to initiate the read operation.



7. While the ECM is reading a Progress bar will display for the user to visually track the read.
8. When the read process is complete the saved file name will display. Select **X** to close

this message.



9. The **Reset Controller** notification will be shown, and the controller reset process will begin.
  1. Turn the vehicle ignition Off.
  2. Click on the Start button to begin the countdown timer.
  3. DO NOT turn the vehicle ignition on until the countdown timer expires. This time is critical to allow the ECM to perform internal functions after a read operation.



User Defined Menu:

Follow the instructions provided by your Tuner to license and flash your controller, alternatively to load the standard menu even when a custom menu is installed, hold the [X] key while powering up the device. Release the key once the splash screen is

visible. The custom menu will revert on next power up.

#### Related Content

- [Pass-Thru Read a Controller](#)
- [Problem Reading a Controller](#)

Comments (0)

---